



B



C

Nivellierung
Leveling
Nivelage




Benutzeranleitung
NIVELLIERFUSS
VAR ISTAR

User Manual
ADJUSTABLE FOOT
VAR ISTAR


Instructions utilisateur
PIED VERIN
VAR ISTAR




1 (4x)



2 (4x)



A



Anzugsdrehmoment: } 3Nm min.
Tightening torque: } 5Nm max.
Couple de serrage: }